



INSTRUCTIONS FOR PROPER USE

FOR USE WITH FLOOR MACHINES

**17" - 20"
(175-350 rpm)**

These pads are meant to be used to remove wear and achieve a wide variety of finishes from dull hone (no shine) to a high polish on Marble, Travertine or Limestone floors walls or counter tops with little to no lippage (uneven tiles).

Follow these simple steps to achieve great results with less mess in less time without the use of harsh chemicals.

1. Sweep or vacuum to remove all abrasive soils.
2. Clean surface with "Stone Cleaner"
3. Rinse surface thoroughly.
4. Center "Monkey Pad" on drive plate on floor machine.
5. 175 rpm machines work best with 60 lbs drive plate. 300-350 rpm machines do not require extra weight.
6. Apply enough water to 2' X 5' are to lightly wet the surface, no need for huge puddles.
7. Move the floor machine in an oval pattern counter clockwise to keep the water inside the work area.
8. Check surface after 15-30 seconds to see if desired results are achieved.
9. If YES, repeat steps 6-8 on the rest of the room one section at a time.
10. Overlap sections by 4'-6" to keep an even finish.
11. If NO, repeat step 7-8 until desired result with that grit is achieved (usually 15-45 seconds per 2' X 5' area).
12. Rinse whole area between grits.
13. Rinse pad well after each use and allow to dry.

FOR USE WITH HAND POLISHER

**7" Variable speed
(600-3000 rpm)**

These pads are meant to be used to remove wear and achieve a wide variety of finishes from dull hone (no shine) to a high polish on Marble, Travertine or Limestone floors walls or counter tops with little to no lippage (uneven tiles).

Follow these simple steps to achieve great results with less mess in less time without the use of harsh chemicals.

1. Dust or vacuum to remove all abrasive soils.
2. Clean surface with "Stone Cleaner"
3. Rinse surface thoroughly.
4. Center "Monkey Pad" on drive plate on hand polisher.
5. Apply enough water to 2' X 3' are to lightly wet the surface, no need for huge puddles.
6. At lowest speed setting, move the tool in an oval pattern counter clockwise to keep the water inside the work area.
7. Check surface after 15-30 seconds to see if desired results are achieved.
8. If YES, repeat steps 6-8 on the rest of the room one section at a time.
9. Overlap sections by 4'-6" to keep an even finish.
10. If NO, repeat step 7-8 until desired result with that grit is achieved (usually 15-45 seconds per 2' X 5' area).
11. Rinse whole area between grits.
12. Rinse pad well after each use and allow to dry.

TIPS

1. Use more water with lower grits and less water with higher grits.
2. To verify if you are finished with any grit level, follow these steps:
Use pad in one spot for 20-30 seconds and squeegee water back, if it looks far better than the rest of the area, keep working it.
3. Use more weight or pressure and less water on grits 3000 and above.

ALL PADS ARE COLOR CODED BY GRIT

200	400	800	1500	3000	8000	11000
DULL HONE	SMOOTH HONE	SATIN HONE	PRE POLISH	POLISH	SHINE	ULTRA SHINE

Visit us online @
www.monkeypads.com

Another Great Product Brought To You By



For questions or comments
please contact our office at
800.280.0333